# Fastener Schedule

| | |
|---|---|
| Wind loads | 90 mph wind speed 26.5ksi Controlling Design Pressure |
| Furring specifications | Wood Furring 5/4"x4" Spaced 16"-24"o.c.--Hat/"Z" 16 gauge 16"-24"o.c. ******(FOR 100-110MPH USE 16'o.c spacing)********** |
| Insulation | No exterior insulation |

| Substrate | starter track to substrate | Length | support clip to substrate | Length | top panel to substrate | Length | Furring wood furring 2x4 or 5/4X4 | starter track to furring | Length | support clip to furring | Length | top panel to furring | Length | Furring hat channel / Z furring 50ksi flange width 1", 1.5" , 2" depth 2" max | starter track to furring | Length | support clip to furring | Length | top panel to furring | Length |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Wood | #8 wood screw | 1 1/4" | #8 wood screw | 1 1/4" | #8 wood screw | 2" | | #8 wood screw | 1 1/4" | #8 wood screw | 1 1/4" | #8 wood screw | 2" | | #8-10 Self Drilling screw | 3/4" | #8-10 Self Drilling screw | 3/4" | #8-10 Self Drilling screw | 2" |
| Metal | #10 self drilling screw | 3/4" | #8-10 Self Drilling screw | 3/4" | #10 self drilling screw | 2" | | | | | | | | | #10 self drilling screw | 3/4" | #8-10 Self Drilling screw | 3/4" | #8-10 Self Drilling screw | 2" |
| CMU | | | | | | | | #8 wood screw | 1 1/4" | #8 wood screw | 1 1/4" | #8 wood screw | 2" | | #10 self drilling screw | 3/4" | #8-10 Self Drilling screw | 3/4" | #8-10 Self Drilling screw | 2" |
| SIP | #8 wood screw | 1 1/4" | #8 wood screw | 1 1/4" | #8 wood screw | 2" | | | | | | | | | | | | | | |
| PEMB | #10 self drilling screw | 3/4" | #8-10 Self Drilling screw | 3/4" | #10 self drilling screw | 2" | | | | | | | | | | | | | | |